




ELECTRIC VEHICLE | LONG-TERM STORAGE

A Club Car vehicle gives you years of trouble-free service when properly maintained. Please follow the recommended long-term storage checklist. For more information on overall vehicle maintenance, consult the owner's manual.



Recommended Vehicle Storage Program



Maintain electrolyte levels from at least 1/2-inch (13 mm) above plates to 1/4-inch (6 mm) below level indicator.

Plug the battery charger into the car. Leave charger plugged in during storage. If your car is equipped with an onboard computer (OBC), it automatically activates the charger when needed.

If the battery charger is left plugged in during extended storage, check the electrolyte level and the charger function at least once per month to ensure that proper operation is maintained. To check charger function, disconnect the DC cord (stationary charger) from the vehicle or the AC cord (onboard charger) from the power source and wait five seconds before reconnecting. The charger is functioning properly if the ammeter indicates current.

If AC power is off for seven or more days, the OBC will not function or charge the vehicle again until it is restarted. To restart the computer:

- a. Ensure AC power has been restored.
- b. Disconnect the DC cord (stationary charger) from the vehicle or the AC cord (onboard charger) from the power source. Wait five seconds and reconnect.

Check tire pressure and inflate to 18-20 PSI or as called for in the owner's manual.

Perform all semi-annual lubrications.

Thoroughly clean the front and rear body, seats, battery compartment and underside of vehicle.

Make sure the storage facility has adequate ventilation called for in the owner's manual.

Do not engage the park brake, but secure the car from rolling. Chock the wheels of vehicle since the forward/reverse lever is in NEUTRAL and the vehicle is in TOW position.

